



K70154 (für 286.102)

K25016 (für 286.102)

K90234 (für 286.104/286.106)

K25012 (für 286.104/286.106)





Pos.	Artikelbeschreibung	Description of item	Artikel Nr./Item No.
K00021 + K00023 + K26212	Türscharnierset	Door hinge set	049033
K00023	Türscharnierset	Door hinge set	=> K00021
K20053	Magnet	Magnet	05900356
K20134	Abstandstück, Gummi	Spacer, rubber	049800
K24010	Zugentlastung PG21	Strain relief PG21	049051
K24014	Schalter, 7-Takt	7-tack switch	049141
K24020	Anschlussklemme	Terminal clamp	06050577
K24040	Kochplatte, rund 2600W, 400V	Cooking plate, round 2600W, 400V	016732
K24051	Kontrolllampe orange	Orange indicator light	E0K00225
K25012	Halterung 50 cm, z. Abgasgitter	Holder 50 cm. f. stack grid	n.m.lieferbar/n.m.available
K25016	Halterung 30 cm, z. Abgasgitter	Holder 30 cm. f. stack grid	049048
K25120	Knebel 6 x 6,4 / 7 Positionen	Knob 6 x 6,4 / 7 positions	049110
K26212	Türscharnierset	Door hinge set	=> K00021
K26234	Fuß komplett, H120/170	Complete base, H120/170	049034
	Fuß komplett, H150/200	Complete base, H150/200	049014
	Fuß H130/190, mit Gewinde	Foot H130/190, w. thread	E026437
K26249	Türgriff, kurz	Short door handle	049035
K70010	Kochmulde, Edelstahl (286102)	Cooking top, stainless steel (286102)	Auf Anfrage/On request
	Kochmulde, Edelstahl (286104)	Cooking top, stainless steel (286104)	061271
	Kochmulde (286106)	Cooking top (286106)	E051090
K70154	Kamingitter, kurz	Short draught diverter grid	049030
K70195	Abdeckung z. Heizplatte	Cover f. hotplate	049998
K90234	Kamingitter, lang	Long draught diverter grid	049031
o.Abb./no pic.	Verbindungssatz	Connection set	049130



Elektroherd 700, B400,
2PL, 4PL, 6PL, UO
Artikel-Nr.: 286102/286104/286106

Ersatzteilliste
15.08.2017